

Acoustic hood/cabinet

Assembly instructions




Acoustic Cabinet Basic page 6
Art no: 2355





Acoustic Hood Everest page 2
Art no: 1250



Acoustic Cabinet Everest v4/v3 page 14
Art no: 2375



Acoustic Hood Basic page 22
Art no: 1859



HINGE ADJUSTMENTS

- 1. Side adjustment +/- 2mm
- 2. Depth adjustment +/- 2mm
- 3. Height adjustment +/- 2mm



1505 (x10)



1582 (x8)



1580 (x8)



1584 (x8)




1586 (x4)



1581 (x1)



2031 (x1)




1585 (x4)



1587 (x4)



1588 (x1)





1



2



3





4



5



6



7



8



9




10




11



Basic Acoustic Cabinet. Art no: 2355







Box 1 of 2



Box 2 of 2

Parts included





Basic Acoustic Cabinet. Art no: 2355



1





2



3










4





Basic Acoustic Cabinet. Art no: 2355





10404 (x1)



1293 (x7)



1505 (x12)



1510 (x20)



1555 (x1)



1545 (x4)



1553 (x2)



5



x12




x2



Basic Acoustic Cabinet. Art no: 2355




1550 (x1)



1548 (x2)



1



2




3



4




5






Acoustic Cabinet Everest v4/v3, Art no: 2375



Box 1 of 2



Box 2 of 2

Parts included



1582 (x8)



1801 (x8)



1505 (x18)



1058 (x16)



1795 (x16)



1794 (x16)



1509 (x44)



1581 (x1)



1585 (x4)



1556 (x1)



1586 (x4)



1587 (x4)




1799 (x4)



1600 (x2)



1599 (x2)



1602 (x2)



2031 (x1)







1273 Index Braille Stapler
(optional, not included)



Acoustic Cabinet Everest v4/v3, Art no: 2375










1509 (x8)




1505 (x8)



1581 (x1)



1801 (x8)



1585 (x4)




1



2



3



4



5






1582 (x8)



1586 (x4)



1587 (x4)



HINGE ADJUSTMENTS

1. Side adjustment +/- 2mm
2. Depth adjustment +/- 2mm
3. Height adjustment +/- 2mm



Acoustic Hood Basic. Art no: 1859

